


**Data Sheet for Micro Touch Rev-Limiter
SeaDoo® 92 - 97 Models**



Fits ALL 92-97 SeaDoo Watercraft 580cc - 720cc. Note: Only HX and SP on 97 models. All others Models are Excluded!

RPM Settings	Jumpers		
	1	2	3
7,250	■	■	■
7,500	••	■	■
7,750	■	••	■
8,000	■	■	••
8,100	■	••	••
8,200	••	■	••
8,300	••	••	■
8,400	••	••	••

<i>Legend</i>	
■	= Jumper - ON
••	= Jumper - OFF



Wires

NOTE:
This Setting above is 7,500 RPM's Limit

Note: Use Dielectric grease on all connections and jumpers. Also make sure that all connections are tight fitting. The connectors will spread apart over time and can be crimped with pliers. If this does not work replace the connector.

NOTE:
SeaDoo and RAVE are registered trademarks of the Bombardier Corporation Trademarks and trade names used in these instructions are property of their respective owners and Micro Touch, Inc. disclaims any proprietary interest in the trademarks and trade names other than its own.